10702 Old Bammel N Houston Rd. Houston, TX 77086 Phone: (713) 462-2118 Fax: (713) 462-2503 Email: cwt@cweldtech.com

# WOC-DOO<sup>TM</sup> WELD OSCILLATOR CONTROL

# **Operation / Installation Manual**

August 13, 2003



OVERVIEW	. 1
NSTALLATION	. 3
OSCILLATOR CONTROL PENDULUM OSCILLATOR CABLES REMOTE CONTROL FUNCTIONS	. 3 . 4 . 5 . 6
DPERATION	. 7
OPERATIONAL SEQUENCES PENDULUM DESCRIPTION	. 7 . 8
WOC-1000 OFF-LINE SERIAL TERMINAL PORT PROTOCOL	. 9
SERIAL TERMINAL PORT INTERFACE PORT PROTOCOL	. 9 . 9 . 9
WOC-1000 PROGRAMMABLE SEQUENCE PROTOCOL	12
PROGRAMMABLE SEQUENCES SPECIFIC COMMAND FUNCTION RELAY OUTPUTS AVAILABLE COMMAND FACTORY DEFAULTS	12 12 12 13 20
	OVERVIEW NSTALLATION OSCILLATOR CONTROL PENDULUM OSCILLATOR CABLES. REMOTE CONTROL FUNCTIONS. OPERATION OPERATION OPERATION OPERATIONAL SEQUENCES. PENDULUM DESCRIPTION WOC-1000 OFF-LINE SERIAL TERMINAL PORT PROTOCOL SERIAL TERMINAL PORT INTERFACE PORT PROTOCOL TERMINAL COMMANDS. WOC-1000 PROGRAMMABLE SEQUENCE PROTOCOL PROGRAMMABLE SEQUENCES SPECIFIC COMMAND FUNCTION RELAY OUTPUTS

APPENDIX A	PENDULUM OSCILLATOR PARTS AND INSTALLATION	A-1
APPENDIX B	WOC-1000 CONTROL ASSEMBLY DRAWINGS	B-1
APPENDIX C	OSCILLATOR MOTOR CABLE ASSEMBLY DRAWING	C-1
APPENDIX D	REMOTE I/O INTERFACE	D-1

# 1.0 OVERVIEW

The Computer Weld Technology Weld Oscillator Control (WOC-1000) is a compact, lightweight, weld torch manipulation control system comprised of the micro-controller based Weld Oscillator Control (WOC-1000) and a stepper motor driven Pendulum Oscillator Assembly (POA). This system is capable of providing independent control of all torch movements in the horizontal plan.

The WOC-1000 provides automatic torch centering using Computer Weld Technology's patented Thru-Arc(tm) sensing technology. The Thru-Arc sensor provides four (4) modes of operation. Mode 0 provides a constant width oscillation with automatic torch centering. Mode 1 provides variable width and centerline control using a depth of penetration parameter to control the width. Mode 2 provides for single right side tracking with constant width and Mode 3 provides for single left side tracking with constant width. The entire seam tracking information is derived from the welding arc and oscillator position. The arc voltage and welding current is measured with an external voltage probe and Hall-Effect clamp on current sensor provided with the system.

The WOC-1000 provides a user definable 50 sequence Programmable Logic Controller (PLC) with four (4) 24-vdc inputs and two N.O. relay contacts. Using the PLC the user can provide external program control and simple power source interface. A RS-232 serial port is provided for off-line programming and system configuration. The RS-232 port can also be used to remote control the WOC-1000.

The Weld Oscillator Control (WOC-1000) provides the necessary command signals to the stepper motor powered drive to permit the selection of the following functions from the front panel of the oscillator control box.

CONTROL	FUNCTION		
RUN	Enables pendulum oscillation.		
TRACK	Enables/Disable Thru-Arc™ tracking.		
JOG	Jog the center position in a CW or CCW direction.		
SPEED	Control the speed of the pendulum oscillation.		
LEFT DWELL	Control the dwell time on the left side of the oscillation pattern.		
CENTER DWELL	Control the dwell time at the center of the oscillation pattern.		
RIGHT DWELL	Control the dwell time on the right side of the oscillation pattern.		
WIDTH	Control the width or amplitude of the weave pattern.		
GAIN	Provides sensitivity control for all tracking functions		

The Pendulum Oscillator Assembly (POA) is a stepper motor driven mechanical assembly that provides the oscillation motion for weld torch manipulation. The oscillator has a single 5/8-inch diameter output shaft for attachment of the user supplied welding torch. The oscillator module can be installed in any position and with a maximum rotational displacement of  $\pm 15^{\circ}$ .

Dimensions	6.62"H X 4.12"W X 8.75"L (168mm X 105mm X 222mm)
Weight	5.5 lbs (2.5kg)
Power Requirements	115 vac or 42 vac 50/60 Hz @ 220 va
Dwell Time	0.02 to 2.0 seconds (left and right)
Velocity	0.24° to 60° per second
Width	± 0.06° to 15°

#### WOC-1000<sup>™</sup> SPECIFICATIONS

#### PENDULUM OSCILLATOR SPECIFICATIONS

Dimensions	4.50"H X 3.37"W X 4.00"L (114mm X 86mm X 102mm)
Weight	3 lbs (1.36kg)
Velocity	0.24° to 60° per second
Output Shaft Rotational Torque	820 ounce/inches
Output Shaft Holding Torque	1657 ounce/inches
Approximate Weight Limit	15 lbs at 3" from center of output shaft

# 2.0 INSTALLATION

#### 2.1 OSCILLATOR CONTROL

The Oscillator control assembly should be located to allow easy operator access to the front panel. The control is provided with four 10-32 captive PEM nuts located on the left side of the enclosure. Figure 1 shows the physical mounting dimensions.



**FIGURE 1 - Control Physical Dimensions** 

#### 2.2 PENDULUM OSCILLATOR

Install the pendulum oscillator on the user supplied welding torch adjustment bracket. The pendulum oscillator may be mounted in any position. The physical oscillation can occur in any position within the 360° rotation of the output shaft. The pendulum oscillator may be installed using the supplied Trans-Torque coupler or any user supplied mounting bracket. The Trans-Torque coupler will grip any 5/8" diameter shaft and can be located in either of the two 1" diameter-mounting holes. See Figure 2 for mounting locations and physical dimensions.



**FIGURE 2- Pendulum Oscillator Physical Dimensions** 

#### 2.3 CABLES

Refer to Figure 3 for the following cable installation. Connect the Pendulum oscillator motor cable to the mating connector on the rear of the control enclosure and to the pendulum oscillator assembly. Connect the power cable to the rear mating connector on the control enclosure. Mount the current sensor such that the welding ground cable passes through the sensor. The RED dot should point toward the power supply for GMAW applications and toward the work piece for GTAW and plasma applications. Connect the current sensor cable to the mating connector on the rear panel. Connect the RED lead for GMAW or BLACK lead for GTAW/Plasma of the voltage probe as close as possible to the welding torch. Connect the other voltage lead to the work piece. Connect the voltage sensor cable to the mating connector on the rear panel. If the WOC-1000 is to be used to control the welding power source connect a suitable remote control cable to DB9 I/O rear panel connect. Refer to Appendix D for sample interconnect drawings for various weld power supplies. This completes the cable installation.



FIGURE 3 - Rear Control Panel Layout

The Oscillator control has a DB-9S remote control connector located on the rear panel. This remote input can be used with the PLC to provide remote control of the WOC-1000. Figure 4 shows the pin-out for the remote connector and the Input/Output configuration for the I/O port.



FIGURE 4 - Remote Input/Output Configuration

#### 2.4 REMOTE CONTROL FUNCTIONS

The following is a functional description of the remote control functions:

PIN	FUNCTIONS
1	INP1 - 24 vdc remote input 1 (24vdc @ 5.0 ma. Active High)
2	INP2 - 24 vdc remote input 1 (24vdc @ 5.0 ma. Active High)
3	INP COM - Digital input signal common
4	INP3 - 24 vdc remote input 1 (24vdc @ 5.0 ma. Active High)
5	INP4 - 24 vdc remote input 1 (24vdc @ 5.0 ma. Active High)
6	CR1-A - CR1 relay Normally Open (N.O.) output (Default weld contactor)
7	CR1-B - CR1 common output (Default Weld contactor)
8	CR2-A - CR2 relay Normally Open (N.O.) output (Default arc active)
9	CR2-B - CR2 common output (Default arc active)

# **3.0 OPERATION**

#### 3.1 OPERATIONAL SEQUENCES

The following operational sequence is based on the default PLC program provided with the unit. The operation may vary based on user defined PLC code. Refer to Section 5 for PLC programming information. Figure 1 shows the location of the operator controls. To operate the control, turn the main power switch to the "Up" position. The power switch will illuminate indicating that the unit is operational. To start the oscillation, turn the "TRACKING" switch to the "On" position. The pendulum oscillator will begin to oscillate. To change the oscillation width, adjust the "WIDTH" control. To change the oscillation speed, adjust the "SPEED" control. To change the right oscillation dwell time, adjust the "RIGHT DWELL" control. To change the left oscillation dwell time, adjust the "LEFT DWELL" control. To move the center of the oscillation pattern use the "JOG" switch. Holding the "JOG" switch in the "CCW" position will move the center of rotation in the CW direction. Holding the "JOG" switch in the "CCW" position will move the center of rotation in the CW direction. To stop the oscillation set the "TRACKING" switch to the "OFF" position.



FIGURE 5 - Front Control Panel Layout

To start a welding sequence turn the "RUN" switch to the "ON" position. The WOC-1000 will activate the CR1 output relay and will wait for an arc on condition. An arc on condition is set when the current is greater then 10 amps and the voltage is greater then 2.5 volts. The arc active signal will be reset if current or voltage falls below preset values. When the arc is active CR2 will be set. When the arc is active the oscillator will start. To activate the selected tracking mode set the "TRACKING" switch to the "ON" position. To disable the selected tracking mode set the "TRACKING" switch to the "OFF" position. While tracking the "GAIN" control can be used to adjust the sensitivity of the centerline tracking.

**NOTE:** If excessive "GAIN" is used the oscillator will over-correct and the weld bead will wonder. Decrease the gain to obtain stable centerline tracking.

To end the welding cycle set the "TRACKING" switch to the "OFF" position. Then set the "RUN" switch to the "OFF" position.

The control will always start the oscillation from the center position as determined when the "RUN" switch is set to the "ON" position. When the "TRACKING" switch is set to the "OFF" position the oscillator will return to the center location. When the "TRACKING" switch is in the "OFF" position the oscillator center position can be moved by activating the "JOG" switch in the "CW" or "CCW" position. When the "JOG" is returned to the center position the control will use the new oscillator position as a center location.

#### 3.2 PENDULUM DESCRIPTION

The pendulum oscillator is a stepper motor device and the rotation is generated as a result of incrementing the motor armature position in 0.75° steps. As the speed of the oscillation is changed, there will be an audible change in the drive motor. The motor noise will change in pitch and level depending on the speed selected. This is a normal operating condition when using a stepper motor.

If the maximum load on the pendulum oscillator shaft is exceeded the motor will not make the incremental step. This excessive loading may cause the motor to lose synchronization and the center position may appear to drift. If the load is high enough the motor will stall. This stall condition will cause the oscillator to produce a very audible noise. This condition will not damage the mechanical drive or the electronic control.

# 4.0 WOC-1000 Off-line Serial Terminal Port Protocol

#### 4.1 SERIAL TERMINAL PORT INTERFACE

The RS-232 communications port is used to off-line program the WOC-1000 PLC sequences drive motor parameters and the operating parameters for the WOC. The Protocol is a simple ASCII command string that allows the user to up-load or download the various parameters. The serial port is configured for the following data format:

Baud Rate:	9600, Full Duplex
Word Length:	8 Data Bits, One Stop and no parity
Hand Shaking:	None

#### 4.2 PORT PROTOCOL

The Protocol consists of a command string and optional data bytes. The command string is an Alpha character an option number followed by a "=" or "?" followed by optional data and terminated with an ASCII "cr" (0dh). The "=" will indicate that data is being sent to the select parameter by the host controller. The "?" will indicate a request for data from the WOC to the Host controller. If the host is up-loading data to the WOC the data will be placed after the "=" character and will be an ASCII string terminated with an ASCII "cr" (0dh). The following is an example of sending a new step motor speed to the WOC-1000:

V1=1000(cr) - Sent from Host

To read the WOC step motor speed, send the following command:

V1?(cr)	<ul> <li>Sent from Host</li> </ul>
1000(cr)	- Received from WOC

#### 4.3 TERMINAL COMMANDS

The following is a summary of the RS-232 serial Commands supported by the WOC-1000:

#### COMMAND DESCRIPTION

A1 - A4 Read WOC-1000 Analog Inputs. The following is a summary of the analog command functions:

- A1 Width Pot analog input (255 = 5.12 vdc Motor Steps = Value \* Scale Factor (M6)).
- A2 Speed Pot input (255 = 5.12 vdc Step Rate = Value \* Rate Multiplier (M5)).
- A3 Right Dwell Pot analog input (255 = 2.55 seconds).
- **A4** Center Dwell Pot analog input (255 = 2.55 seconds).
- **A5** Left Dwell Port analog input (255 = 2.55 seconds).
- A6 Gain Pot analog input (255 = 5.12 vdc).
- A7 Current sensor excitation current (255 = 255 ma.)
- **A8** Set motor Excitation current reference (255 = 2.55 amps).

- M0 M5 Set system control mode functions:
  - M0 Set programmable sequence number to value.
  - M1 Read Switch input status (1 = on, 0 = off)

BIT 0 = Remote INP1 (value= 1). BIT 1 = Remote INP2 (value= 2). BIT 2 = Remote INP3 (value= 4). BIT 3 = Remote INP4 (value= 8). BIT 4 = "CW" rotate switch input (value= 16). BIT 5 = "CCW" rotate switch input (value= 32). BIT 6 = "RUN" switch input (value= 64). BIT 7 = "Track" switch input (value= 128).

M2 - Set output relays CR1 - CR2 (1=on, 0=off).

BIT 0 = Relay CR1 (value= 1) BIT 1 = Relay CR2 (value= 2)

- M3 Set Step motor current value #.## amps (.55 2.55 amps).
- M4 Set Current sensor excitation value (1 255).
- M5 Set motor step rate multiplier value. Motor speed = [1 / (Value x Rate)].
- M6 Step motor scale factor (Steps / Distance).
- M7 Analog input automatic scan starting parameter (0 5). When the value is set to zero the front panel pot values will be used. To disable the pot controls set the scan value to 6. This will enable off-line programming of the oscillator parameters.
- **M8** CWT LAN Id number. Set an LAN ID value will disable the RS-232 communications and enable the LAN communications routines (Range 1 4).
- M9 Enable WOC auto sequence routines.

Command	Function
M9=1	Enable Auto sequence input
M9=2	Clear Auto sequence input
M9=3	Set Initialize sequence input
M9=4	Calculate maximum position based on external limit switch inputs.

- M10- Cross Seam tracking gain.
- M11- Spare Parameter not used.
- M12- Enable/Disable tracking data up-load (1 = Enable, 0 = Disable).
- M13- Set Tracking mode: 0 = Center line Tracking.
  - 1 = Width control tracking.
    - 2 = Left side Tracking with constant width
    - 3 = Right side tracking with constant width.
    - \*\*\*\*\*\*\*\*\* Firmware Version 1.22 or higher \*\*\*\*\*\*\*\*\*
    - 4 = AVC torch height control (Ver 1.22 or greater)
    - 5 = ACC Torch Height control (Ver 1.22 or greater)
- **M14-** Depth of penetration value used for tracking modes 1 2. The value controls the depth of penetration of the arc into the sidewall of the welding bevel.
- **S1 S75** Programmable Sequence Commands See Section 5.0 for description of programmable sequence commands and data format.

- V1 V9 Write/Read double byte variables:
  - V1 = Oscillator speed value.
  - V2 = Current Drive Position (Scaled step motor count).
  - V3 = Move position value. Decrement by the step motor drive command.
  - V4 = Maximum oscillator position limit.
  - V5 = Oscillator center position.
  - **V6** = Oscillator width.
  - V7 = Maximum Oscillation width limit used by the adaptive width tracking mode 1.
  - V8 = Minimum Oscillation width limit used by the adaptive width tracking mode 1.
  - **V9** = Current torch to work position.
  - V10= Maximum cross seam correction limit.
  - V11= Maximum torch to work correction limit.

  - V12= Torch to work reference voltage used in tracking mode 4 and 5
  - V13= Torch to work reference current used in tracking mode 4 and 5
  - V14= Actual Arc Voltage value (0.1 volt increments, 100 = 10.0 volts)
  - V15= Actual Arc Current value (1 amp increment, 100 = 100 amps)

In addition to the terminal commands the WOC-1000 supports several special control key functions. These functions are used to save the programmed data in the EEPROM and to clear any pending terminal commands. The following commands are generated by pressing the CTRL" and specified letter key at the same time. When sending any of the following control codes, the WOC-1000 will respond with an ASCII "CR". The following is a summary of the special control character function supported by the WOC-1000:

<b>^W</b>	Save current parameters and sequence values to WOC-1000 EEPROM
^C	Reset the terminal serial port and clear any pending terminal commands.
^S	Up-load stored sequence commands from WOC to terminal.
^R	Load sequence commands from EEPROM to RAM

#### 5.0 - WOC-1000 Programmable Sequence Protocol

#### 5.1 **PROGRAMMABLE SEQUENCES**

The WOC programmable sequence consists of a 3-byte command. The First byte is the command byte followed by a two-byte value:

#### {Byte1}, {Byte2 (MSB)(:)Byte3 (LSB)}

The value bytes must be set even if not required by the command. The value bytes may be branch addresses or real data passed to the selected function. The Command and value must be separated by a comma. The MSB byte and LSB byte of the value may be separated by a colon (":"). The colon will cause the MSB and LSB byte to concatenate to form a single two-byte value.

#### 5.2 SPECIFIC COMMAND FUNCTION

When setting MSB and LSB bytes for specific command function the MSB and LSB byte may be separated by a ":" or the total value may be specified by the decimal equivalent of the two bytes. To set the decimal value for the MSB and LSB bytes use the following equation:

Decimal Value = (MSB x 256) + LSB

The following is an example of how to set sequence 4 to the "SWITCH ON" command (1) and branch to sequence number 10 when "OFF" (MSB) and to test switch input 1 (LSB):

Decimal Value = (MSB x 256)+LSB = (10 x 256)+1 = 2561

Decimal Command sent to WOC: **S4=1,2561** Optional Command format: **S4=1,10:1** 

#### 5.3 RELAY OUTPUTS

When Setting / Resetting the relay outputs the individual relays are selected by setting the decimal value for each relay and use the result as the value for the command. The following is an example of programming sequence 5 to set relay CR1 and CR2 using the "SET RELAY" command (2):

Decimal Value for CR1 = 1 and CR6 = 3 Decimal Value = 1 + 2 = 3Command sent WOC: **S5=2,3**  The following is the decimal value for individual bits used for the relay outputs and switch inputs:

BIT NUMBER	DECIMAL	RELAY	SWITCH INPUT SWITCH
BIT 0	1	CR1	INP1
BIT 1	2	CR2	INP2
BIT 2	4	N/A	INP3
BIT 3	8	N/A	INP4
BIT 4	16	N/A	"CW" Switch
BIT 5	32	N/A	"CCW" Switch
BIT 6	64	N/A	"RUN" Switch
BIT 7	128	N/A	"TRACK" Switch

#### 5.5 AVAILABLE COMMAND

The following is summary of the available commands and the required values:

#### COMMAND DESCRIPTION

**0** NOP - No Operation increment to next sequence

Example: S20=0,0 ;Skip sequence - No operation.

**1 SWITCH ON** - LSB selects switch input MSB is branch to sequence number if switch is "OFF". If MSB is zero, function will wait for switch "ON" condition then increment to next sequence.

Example 1:	S20=1,0:1	;Wait for input 1 "ON".
Example 2:	S20=1,40:1	;If input 1 is "OFF" branch to SEQ40. If "ON" increment
		to next sequence

2 **SWITCH OFF** - LSB selects switch input, MSB is branch to sequence number if switch is "ON". If MSB is zero, function will wait for switch "OFF" condition then increment to next sequence.

Example 1:	S20=2,0:1	;Wait for input 1 "OFF".
Example 2:	S20=2,40:1	;If input 1 is "ON" branch to SEQ40. If "OFF" increment
		to next sequence

**3 SET RELAY** - Set relay output specified by LSB byte (CR1 = 64 and CR2 = 128).

Example 1:	S20=3,2	;Set CR2 relay output.
Example 2:	S20=3,3	;Set CR1 and CR2 relay output

4 **CLEAR RELAY** - Clear relay output specified by LSB byte (CR1 = 64 and CR2 = 128).

Example 1:	S20=4,2	;Reset CR2 relay output.
Example 2:	S20=4,3	;Reset CR1 and CR2 relay output

5 **DELAY TIME** - Delay program execution by time specified by the value. The value specified is in 10 msecond increments. (Example: 13,50 Set delay time to 0.50 seconds)

Example: S20=5,20 ;Delay for 0,20 seconds.

6 AUTO EXECUTE - If the Auto execute input is active branch to LSB sequence. If the Auto Execute input is not active branch to sequence number specified by the MSB. If MSB is 0 the function will wait until the input becomes active. If input is active the function will branch to the sequence number specified by the LSB byte. If the LSB is 0 the function increment to the next sequence.

Example: S20=6,10:20 ;If the auto active flag is set jump to SEQ 20 else jump to SEQ 10.

7 **INITIALIZE** - If the Initialize input is active branch to LSB sequence. If the Initialize input is not active branch to sequence number specified by the MSB. If MSB is 0 the function will wait until the input becomes active. If input is active the function will branch to the sequence number specified by the LSB byte. If the LSB is 0 the function increment to the next sequence.

10

Example: S20=7,10:20 ;If the initialize flag is set jump to SEQ 20 else jump to SEQ

8 **CLEAR INITIALIZE** - Clear initialize input.

		<u> </u>	
Example:	S20=8,0	;Clear Initialize Fla	ıg.

**9 HALT MOVE** - Halt current move command and stop stepper drive motor.

Example: S20=9,0 ;Halt current move command and stop motor drive.

**10 SET SPEED** - Value equal new drive velocity [LSB] (1 - 255).

Example: S20=10,20 ;Set motor speed to low speed ( [1 / (Value \* Rate)] ).

11 SET POSITION - Set current position to value specified by [MSB:LSB].

Example: S20=11,1000 ;Set current position to 1000.

12 **SAVE POSITION** - Save current position encoder count to temporary position register and increment to next sequence.

Example: S20=12,0 ;Save current position.

**13 RESTORE POSITION** - Move to position saved in temporary position register and increment to next sequence.

Example: S20=13,0 ;Restore save position and move oscillator to the saved position.

**MOVE TO POSITION** - Move to position and increment to next sequence.

Example:	S20=14,1000	;Move oscillator to position specified.
----------	-------------	---

**SET MAXIMUM POSITION** - Set maximum position limit to value specified.

	Example:	S20=15,10000	;Set oscillator maximum to position 10000.
16	LOAD POSITION	TO MAX - Set	maximum position limit to current position.
	Example:	S20=16,0	;Load current oscillator position to Max position.
17	JOG POSITION C position.	<b>W</b> - Add value	specified to current position and move to new
	Example:	S20=17,100	;Jog current position 100 steps in the CW direction.
18	JOG POSITION C new position.	CW - Subtract	value specified from current position and move to
	Example:	S20=18,100	;Jog current position 100 steps in the CCW direction.
19	MOVE COMPLET is set the function v complete. If the LS then increment to t LSB.	<b>E</b> - Has drive co will jump to the s SB byte is zero he next sequer	ompleted the last move command? If the MSB byte selected sequence number if the move is not the function will wait for the move to be completed nce or branch to the sequence number set by the
	Example 1: Example 2:	S20=19,0 S20=19,40:0	;Wait for oscillator move complete ;Is oscillator move complete? No - Branch to SEQ 40
20		ITER - Load so	lected loop counter (0-4) with starting value MSB

**20 SET LOOP COUNTER** - Load selected loop counter (0-4) with starting value. MSB byte is the value to load and the LSB byte is the selected counter. There are 5 Loop counters available.

Example:	S20=20,25:1	;Load Loop counter 1 with a value of 25.
----------	-------------	--

21 **INCREMENT LOOP COUNTER** - Increment the selected counter (0 - 4) and set the condition code register. The LSB byte selects the loop counter to Increment.

Example:	S20=21,1	;Increment Loop counter 1 and set condition code
-		register.

22 DECREMENT LOOP COUNTER - Decrement the selected counter (0 - 4) and set the condition code register. The LSB byte selects the loop counter to decrement.

Example: S20=22,1 ;Decrement Loop counter 1 and set condition code register.

**23 CLEAR LOOP COUNTER** - Clears the selected loop counter (0 - 4). The LSB byte selects the desired loop counter to be cleared and sets the condition code register.

Example: S20=23,1 ;Clear Loop counter 1 and set condition code register.

24 JUMP TO SEQUENCE - Jump to sequence specified by LSB byte.

Example: S20=24,40 ;Jump to sequence S40.

**25 JUMP SUBROUTINE** - Jump to specified sequence number subroutine. The sequence subroutine must be terminated with a return from subroutine command (32). The WOC allows nesting of up to 5 subroutines. All commands may be used in subroutines.

Example: S20=25,40 ;Jump to subroutine at sequence S40.

26 **RETURN FROM SUBROUTINE** - Returns the sequence counter to the "jump subroutine " sequence number plus 1. If a return subroutine command is executed

with out a "jump subroutine " the sequence counter will be incremented to the next sequence.

Example: S20=26,0 ;Return from subroutine.

27 COMPARE VALUE TO POSITION - Compares the value (MSB, LSB) to the current position and set the condition code register. The comparison is a subtraction of the current position from the command value (CURRENT POSITION - COMMAND VALUE). The current position is unchanged as a result of the command. Only the condition code register is set.

Example: S20=27,1000 ;Compare current position to 1000 and set condition code register.

28 COMPARE SWITCH INPUT - Compares the current WOC-1000 switch inputs to the binary value specified in the LSB byte (SWITCH - VALUE) and sets the condition code register.

Example:	S20=28,3	;Compare input to 3 (Input 1 and 2 active) and set
		condition code register.

29 COMPARE LOOP VALUE - Compares the loop counter specified by the LSB byte to VALUE).

Example: S20=29,10:1 ;Compare Loop counter 1 to 10 and set condition code registers.

**30 BRANCH NOT EQUAL** - Branch to sequence specified by LSB byte as a result of the previous parameter value not being equal to command value or not equal zero. As specified by the condition code register. If not zero increment to next sequence number.

Function: (Parameter != Compare) then Branch to Seq #

Example: S20=30,40 ;If comparison parameter is not equal to value branch to SEQ 40.

**31 RANCH IF LOWER** - Branch to sequence specified by LSB as a result f the previous parameter value being less than the command value. As specified by the condition code register. If not less than stored value increment to next sequence number.

Function: Parameter < Compare then Branch to Seq #

Example: S20=31,40 ;If comparison parameter < value branch to SEQ 40.

**32 BRANCH IF HIGHER** - Branch to sequence specified by LSB byte as a result of the previous parameter value being greater than the command value. As specified by the condition code register. If not greater than parameter value increment to next sequence number.

Function: Parameter > Compare then Branch to Seq #

Example: S20=32,40 ;If comparison parameter > value branch to SEQ 40.

**33 BRANCH IF EQUAL** - Branch to sequence specified by LSB byte as a result of the previous parameter value being equal to the command value (Note: result of comparison is zero). As specified by the condition code register. If not equal to parameter value increment to next sequence number.

Function: Parameter = Compare then Branch to Seq #

Example: S20=33,40

**34 BRANCH IF HIGHER OR EQUAL** - Branch to sequence specified by LSB byte as a result of the previous parameter value being greater than or equal to the command value. As specified by the condition code register. If not greater than command value increment to next sequence number.

Function: Parameter >= Compare then Branch to Seq #

Example: S20=34,40 ;If comparison parameter => to value branch to SEQ 40.

**35 BRANCH IF LESS THEN OR EQUAL** - Branch to sequence specified by LSB byte as a result of the previous parameter value being less than or equal to the command value (Note: result of comparison is zero). As specified by the condition code register. If not equal to parameter value increment to next sequence number.

Function: Parameter <= Compare then Branch to Seq #

Example: S20=35,40 ;If comparison parameter <= to value branch to SEQ 40.

**36 START OSCILLATOR** - Start the mechanical oscillation based on current width, speed, and dwell parameters.

Example: S20=36,0 ;Start oscillation.

37 STOP OSCILLATOR - Halt the current oscillation and move oscillator to the current center position.

Example: S20=37,0 ;Stop oscillation.

**38 START TRACKING** - Start centerline tracking with the mode specified by the [LSB] byte. The following are the valid tracking mode commands: 0 = Centerline tracking, 1 = Width control tracking, 2 = Right side tracking, 3 = Left side tracking.

Example 1: S20=38,0	Start tracking using the centerline mode
Example 2: S20=38,1	Start tracking using the width mode
Example 3: S20=38,2	Start tracking using the Right side mode
Example 4: S20=38,3	Start tracking using the Left side mode

**39 STOP TRACKING** – Disable the centerline tracking functions.

Example: S20=39,1 Disable center line tracking

40 CR1 ON/OFF - Activate CR1 based on the [LSB] specified input. If the [LSB] input is active set CR1,. If the [LSB] byte specified input is inactive reset CR1.

Example: S20=38,1 ;Set/Reset CR1 based on input 1 status

41 CR2 ON/OFF - Activate CR2 based on the [LSB] specified input. If the [LSB] input is active set CR2,. If the [LSB] byte specified input is inactive reset CR2.

Example: S20=39,1 ;Set/Reset CR2 based on input 1 status

42 OSCILLATOR ON/OFF – Activate the Oscillator based on the [LSC] specified input. If the [LSB] input is active start the Oscillator. If the [LSB] byte specified input is inactive stop the oscillator.

Example: S20=40,1 ;Start/Stop the oscillator based on input 1 status

**43 TRACK ON/OFF** - Activate the tracking mode specified by the [MSB] based on the [LSB] specified input. If the [LSB] input is active, start the tracking mode specified by the [MSB] byte. If the [LSB] byte is inactive disable the tracking function. The following are the valid tracking mode [MSB] values: 0 = Centerline tracking, 1 = Width control tracking, 2 = Right side tracking, 3 = Left side tracking.

 Example 1: S20=43,0:1
 If INP 1 is active start tracking using the centerline mode

 Example 2: S20=43,1:1
 If INP 2 is active start tracking using the width mode

 Example 3: S20=43,2:1
 If INP 1 is active start tracking using the width mode

 Example 4: S20=43,3:1
 If INP 1 is active start tracking using the Right side mode

 JOG CW ON/OFF - Jog the oscillator center position in the CW direction by the value

 aposition in the IMSPI bute
 The IL SPI aposition to the input to toot.

44 JOG CW ON/OFF - Jog the oscillator center position in the CW direction by the value specified in the [MSB] byte. The [LSB] specifies the input to test. If the [LSB] specified input is active jog the center position by the value specified in the [MSB] byte. If the [LSB] byte is inactive the change center position is unchanged.

Example: S20=41,10:1 ;If INP 1 is active increment center position 10 steps in the CW direction

**45 JOG CCW ON/OFF** - Jog the oscillator center position in the CCW direction by the value specified in the [MSB] byte. The [LSB] specifies the input to test. If the [LSB] specified input is active jog the center position by the value specified in the [MSB] byte. If the [LSB] byte is inactive the change center position is unchanged.

Example: S20=42,10:1 ; If INP 1 is active increment center position 10 steps in the CCW direction

**46** WAIT FOR ARC ON CONDITION - Wait for valid arc condition defined by arc voltage greater then 2.5 volts and current greater then 10 amps. If MSB byte is set the function will branch to the selected sequence number while the ARC ON Flag is clear. If the LSB is set and the "ARC ON" flag is set the function will branch to the specified sequence. If the LSB is zero the function will increment to next sequence.

Example 1: S20=46,0Wait for Arc Active.Example 2: S20=46,40:30If Arc is not active branch to SEQ 40. If Arc is active branch to SEQ 30

**47 SET WIDTH** - Set oscillation width control to [LSB] (0 - 255) value. This function is used to set a default width Pot value when the auto scan function is set to 5 to disable user Pot controls.

Example: S20=47,20 ;Set oscillation width to LSB value.

#### 

**48 SET RIGHT DWELL** - Set oscillation Right Dwell control to [LSB] (0 - 255) value. This function is used to set a default Right Dwell Pot value when the auto scan function is set to 5 to disable user Pot controls.

Example: S20=48,20 ;Set oscillation Right Dwell to LSB value.

**49 SET LEFT DWELL** - Set oscillation Left Dwell control to [LSB] (0 - 255) value. This function is used to set a default Left Dwell Pot value when the auto scan function is set to 5 to disable user Pot controls.

Example: S20=49,20 ;Set oscillation Left Dwell to LSB value.

**50 SET CENTER DWELL** - Set oscillation Center Dwell control to [LSB] (0 - 255) value. This function is used to set default Center Dwell Pot value when the auto scan function is set to 5 to disable user Pot controls.

Example: S20=50,20 ;Set oscillation Center Dwell to LSB value.

**SET TRACKIN GAIN** - Set Cross Seam Tracking Gain control to [LSB] (0 - 255) value. This function is used to set default Tracking Gain Pot value when the auto scan function is set to 5 to disable user Pot controls.

Example: S20=51,20 ;Set Tracking Gain to LSB value.

52 SET VOLT REFERANCE - Set Voltage reference to the value and increment to the next sequence. This value is used as a reference for torch height control tracking mode 4 or 5. The units are in 0.1-volt increments (i.e. 100 = 10.0 volts)

Example: S20=52,230 ;Set Torch tracking voltage to 23.0 volts.

**53 SET CURRENT REFERANCE** - Set Current reference to the value and increment to the next sequence. This value is used as a reference for torch height control tracking mode 4 or 5. The units are in 1-amp increments (i.e. 100 = 100 amps).

Example: S20=53,220 ;Set Torch height to 220 amps.

54 **TOUCH-RETRACT** – This command provides an automatic touch retract torch routine. The [MSB] byte sets the retract distance and the [LSB] sets the step down increments. When this command is executed the Torch slide will be move down until the sensed arc voltage falls below 0.8 volts. The command will then halt the down ward motion and back up the number of steps set in the [MSB] byte. This routine requires an external voltage source be applied to the torch and is normally used with GTAW application.

Example: S20=54,100:2 ; 100 step retract and 2 step down increment .

55 HOME SLIDE – Find Upper home position of a vertical slide assemble. Requires external N.C. upper limit switch to indicate home position. The [LSB] byte specifies the remote input used to indicate the Home position. This command will set the current slide position to the user defined V4 max position limit and will move the slide up until the selected remote input [LSB] is inactive or the max position step count has been reached.

Example: S20=55,1 ;Home vertical slide using INP1 as home limit.

**56 SET VOLT REF TO POT** - Set Volt reference, for torch height tracking, to the Pot value specified by the [LSB]. This function is used to set torch Tracking reference voltage to the value controlled by the selected control panel pot. The auto scan function must be enabled. The [LSB] sets the control pot that is used (0 = A1...5 = A6).

Example: S20=56,1 ;Set Volt Reference to the Width Pot.

**57 SET CURRENT REF TO POT** - Set Current reference, for torch height tracking, to the Pot value specified by the [LSB]. This function is used to set torch tracking reference current to the value controlled by the selected control panel pot. The auto scan function must be enabled. The [LSB] sets the control panel pot that is used (0 = A1... 5 = A6).

Example: S20=56,3 ;Set Current Reference to the Center Dwell Pot.

58 MOVE SLIDE CW BY INPUT VALUE – Move slide in CW direction based on Input Value specified by the [LSB] at the speed specified by the [MSB]. This function moves

the slide in the CW Direction when the Input Value is equal to the Value in the [LSB] at the speed indicated in the [MSB].

Example: S20=58,200:16 ;If Input Value Equals 16 (Input 5 is Active) Move Slide Down at Speed of 200.

**59 MOVE SLIDE CCW BY INPUT VALUE** – Move slide in CCW direction based on Input value specified by the [LSB] at the speed specified by the [MSB]. This function moves the slide in the CCW Direction when the Input Value is equal to the value in the [LSB] at the speed indicated in the [MSB].

Example: S20=58,200:16 ;If Input Value Equals 16 (Input 5 is Active) Move Slide UP at Speed of 200.

#### 5.6 FACTORY DEFAULTS

As shipped from the factory the WOC-1000 has a basic operation PLC program. The PLC code allows the user to start/stop the welding process using the "RUN" switch. By connecting the CR1 relay output to the "Gun Switch" input on the wire feeder the WOC-1000 will activate the welding system. When an arc is established the oscillator will be activated. The centerline-tracking mode will be activated when the operator activates the "TRACKING" switch. The PLC code is divided into three (3) sections. The first section is the non-welding routine and consists of Sequence 1 - 5. This section checks the various input control switches and will jog the oscillator center, start/stop the oscillator and start the welding sequence. The second section is the welding routines. When the "RUN" switch is active the CR1 relay is set and the PLC code will wait for an arc on condition. When the arc is established the oscillator will automatically start. When the "TRACKING" switch is activated the WOC-1000 will begin centerline tracking. To change the mode of tracking the user will need to change line S10 to reflect the desired tracking mode. The operator can also jog the oscillation center position using the "JOG" control switch. The following is a listing of the default PLC program provided:

=================	====== NON WELD SWITCH TEST ROUTINE ====================================
S1=4,3	RESET ALL RELAYS
S2=44,10:16	IF CW SWITCH ON - JOG OSC CENTER IN 10 STEP CW INCREMENTS
S3=45,10:32	IF CCW SWITCH ON - JOG OSC CENTER IN 10 STEP CCW INCREMENTS
S4=42,128	IF TRACK SWITCH ON - START/STOP OSCILLATOR
S5=1,1:64	IS RUN SWITCH ON - NO GO TO SEQ 1
================	===== WELD "ON" ROUTINE ====================================
S6=3,1	SET RELAY 1 "WELD CONTACTOR"
S7=46,5:8	IS ARC ACTIVE? NO - GO TO S5 AND RECHECK WELD SWITCH "ON"
S8=5,25	DELAY FOR .25 SECS FOR ARC STABILIZATION.
S9=3,2	SET ARC ACTIVE RELAY CR2
S10=36,0	YES - START OSCILLATOR
S11=43,0:128	START/STOP CENTER LINE TRACKING BASED ON TRACKING SWITCH?
S12=1,16:64	IS WELD SWITCH STILL ON - NO GOTO S16 AND END WELD ROUTINE
S13=44,10:16	IF CW SWITCH ON - JOG OSC CENTER IN 10 STEP CW INCREMENTS
S14=45,10:32	IF CCW SWITCH ON - JOG OSC CENTER IN 10 STEP CCW INCREMENTS
S15=46,16:11	IS ARC STILL ACTIVE - NO GOTO S15 ELSE GOTO S11
===================	======= END WELD CYCLE ====================================
S16=39,0	STOP CENTER LINE TRACKING
S17=37,0	STOP OSCILLATOR
S18=4,3	RESET CR1 "WELD CONTACTOR" AND CR2 "ARC ACTIVE" RELAYS
S19=2,64	WAIT FOR WELD SWITCH OFF
S20=24,1	JUMP TO SEQ 1

# **APPENDIX A - PENDULUM OSCILLATOR PARTS AND INSTALLATION**



	]		
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	E2A5179	Pendulum Oscillator Assembly
2	1	E2A5187	Pendulum Oscillator Adjustable Mount Assembly
3	1	E2A5186	Pendulum Oscillator Adjustable Arm Assembly
4	1	E2A5185	Adjustable Torch Mount Assembly

#### FIGURE A1: Typical Installation Parts for Pendulum Oscillator



FIGURE A2: Optional Mounting Configurations of Adjustable Mount Assembly – E2A5187



**Threaded Hole Mounting** 

FIGURE A3: Optional Mountings Holes Configurations for Base Mounting Plate



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	E2M5520	Bearing Spacer
2	1	E2M5798	Housing
3	1	E2M5799	Cover
4	1	E2M5800	Output Shaft
5	1	E2M5801	Adaptor Shaft
6	1	E2M5609	Worm Gear
7	2	X2B5054	Bearing
8	1	X2G5021	Worm
9	1	X3M5034	Stepper Motor
10	1		3/32" Dia. x 1/2" Lg. Roll Pin
11	1		5/64" Dia. x 3/8" Lg. Roll Pin
12	4		#10-32 x 5/8" Lg. Socket Cap Hd. Screw
13	4		#10-32 x 1" Lg. Socket Cap Hd. Screw

#### FIGURE A4: Exploded View of Pendulum Oscillator Assembly - E2A5179



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	E2M5821	Pendulum Oscillator Shaft Mounting Plate
2	1	E2M5822	Pendulum Oscillator Base Mounting Plate
3	1	X2U5010	5/8" Dia. x 12" Long 303 SS Shaft
4	2	X6B5157	Transtorque Coupling
5	2		1/4-20 x 7/8" Long Socket Flat Head Screw

#### FIGURE A5: Exploded View of Pendulum Oscillator Adjustable Mount Assembly - E2A5187



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	S2M5176	Clutch Bracket
2	1	E2M5812	Pendulum Oscillator Shaft Sleeve
3	1		#10-32 x ¾" Long Socket Head Cap Screw
4	1		#1/4-20 x 7/8" Long Socket Head Cap Screw
5	1		5/16" Dia. x 1⁄2" Long x #1/4-20 Shoulder Screw

FIGURE A6: Exploded View of Pendulum Oscillator Adjustable Arm Assembly - E2A5186



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	E2M5711	Binzel Bracket Arm
2	1	E2M5817	Torch Mount Arm Base
3	1	E2M5818	Torch Mount Clamp Base
4	2	E2M5819	Torch mount Insulator
5	3		#10-32 x 5/8" Long Socket Flat Head Screw
6	4		#10-32 x 1/2" Long Socket Flat Head Screw
7	4		#1/4-20 x 2-1/2" Long Socket Flat Head Screw

FIGURE A7: Adjustable Torch Mount Assembly - E2A5185



FIGURE A8: Physical Dimensions for Pendulum Oscillator - E2A5179



FIGURE A9: In-Line Shaft with Top Mounted Base Mounting Plate



FIGURE A10: In-Line Shaft with Side Mounted Base Mounting Plate



FIGURE A11: In-Line Shaft with Back Mounted Base Mounting Plate



FIGURE A12: Right Angled Shaft with Top Mounted Base Mounting Plate



FIGURE A13: Right Angled Shaft with Side Mounted Base Mounting Plate



FIGURE A14: Right Angled Shaft with Side Mounted Base Mounting Plate

# APPENDIX B - WOC-1000 CONTROL ASSEMBLY

ITEM	QTY	PART NO	DESCRIPTION	
1	1	E5A5027	Control P.C.B. Assembly	
2	1	E5A5028	Front Panel P.C.B. Assembly	
3	1	E3E5010	Cover	
4	1	E3E5012	Enclosure	
5	1	E3E5013	Front Overlay	
6	1	E3E5014	Rear Overlay	
7	1	E3W5037	Power In Cable	
8	1	E3W5038	Power Out Cable	
9	1	E3W5039	Motor Cable	
10	1	E3W5040	Current Cable	
11	1	E3W5041	Voltage Cable	
12	1	E3W5042	Term Cable	
13	1	E3W5043 Remote Cable		
14	1	E3E5015	E3E5015 Heatsink	
15	1	E5I5002	Processor	
16	2	X3Z5027	D-Sub Screwlock Kit	
17	2	X5Z5007	Shoulder Washer	
18	6	X6A5015	Knob	
19	3	X3Z5038	Dress Nut	
20	1	X3S5078	Rocker Switch	
21	1	X3T5067	Power Supply	
22	2		4-40 X 1/4" Lg. Pan Hd. Screw w/ Lock Washer	
23	4		6-32 X 3/8" Lg. Socket Hd. Cap Screw	
24	8		6-32 X 1/4" Lg. Pan Hd. Screw w/ Lock Washer	
25	1		6-32 Hex Nut	
26	8		6-32 X 1/4" Lg. Black Socket Button Hd. Screw	
27	A/R		Termal Compound	
28	1.5"		Kapton Tape	
29	1	A3W0155	2" 16 Pin IDC Cable	

#### FIGURE B1: WOC-1000 Enclosure Assembly P/N: E3A5056



FIGURE B1: WOC-1000 Enclosure Assembly P/N: E3A5056

DESCRIPTION	WIRE COLOR	FROM	ТО
Hot	Brown	Item 1 - Pin A	Item 5 - E4
Neutral	Blue	Item 1 - Pin B	Item 6 - E6
Neutral	Blue	ltem 6 - E6	Item 2 - Pin 3
Ground	Green	Item 1 - Pin C	Item 4 - E1
Ground	Green	ltem 4 - E2	Item 5 - E3
Hot	Black	ltem 5 - E5	Item 2 - Pin 1

ITEM	QTY	PART NO	DESCRIPTION
1	1	X3P5637	3 Circuit Receptacle
2	1	X3P5638	3 Circuit Housing
3	3'	X3W5079	Crimp Terminal
4	2		Solder Terminal
5	3		18 AWG 1/4" Push-On Terminal
6	1		14 AWG 1/4" Push-On Terminal
7	8		Cable Tie
8	1.3'		18 AWG Brown CSA Type TR-64 Coated Wire
9	1.7'		18 AWG Blue CSA Type TR-64 Coated Wire
10	1.4'		18 AWG Green CSA Type TR-64 Coated Wire
11	0.4'		18 AWG Black CSA Type TR-64 Coated Wire

#### FIGURE B2: Power In Cable Assembly P/N: E3W5037



FIGURE B2: Power In Cable Assembly P/N: E3W5037

DESCRIPTION	WIRE COLOR	FROM	ТО
+24V	Red	J1 - Pin 1	J2 - Pin 1
+24V	Red	J1 - Pin 2	J2 - Pin 2
+24V	Red	J1 - Pin 3	J2 - Pin 3
Common	Black	J1 - Pin 4	J2 - Pin 4
Common	Black	J1 - Pin 5	J2 - Pin 5
Common	Black	J1 - Pin 6	J2 - Pin 6

ITEM	QTY	PART NO	DESCRIPTION
1	2	X3P5019	6 Circuit Housing
2	12	X3P5077	Crimp Terminal
3	3		Cable Tie
4	1.7'		18 AWG Red CSA Type TR-64 Coated Wire
5	1.7'		18 AWG Black CSA Type TR-64 Coated Wire



# FIGURE B3: Power Out Cable Assembly P/N: E3W5038

DESCRIPTION	WIRE COLOR	FROM	ТО
Motor /A	Orange	ltem 1 - Pin 2	Item 3 - Pin B
Motor A	Black	Item 1 - Pin 1	Item 3 - Pin A
Motor B	Red	Item 1 - Pin 3	Item 3 - Pin C
Motor /B	Yellow	Item 1 - Pin 4	Item 3 - Pin D

ITEM	QTY	PART NO	DESCRIPTION
1	1	X3P5577	4 Circuit Receptacle
2	4	X3P5578	Crimp Terminal
3	1	X3P5639	5 Circuit Receptacle
4	2		Cable Tie
5	0.5'		16 AWG Orange CSA Type TR-64 Coated Wire
6	0.5'		16 AWG Black CSA Type TR-64 Coated Wire
7	0.5'		16 AWG Red CSA Type TR-64 Coated Wire
8	0.5'		16 AWG Yellow CSA Type TR-64 Coated Wire



# FIGURE B4: Motor Cable Assembly P/N: E3W5039

DESCRIPTION	WIRE COLOR	FROM	ТО
SEN+	Red	Item 1 - Pin 1	ltem 3 - Pin A
AMP+	White	Item 1 - Pin 2	ltem 3 - Pin B
AMP-	Green	Item 1 - Pin 3	Item 3 - Pin C
SEN-	Black	Item 1 - Pin 4	ltem 3 - Pin D
Shield	Yellow	Item 1 - Pin 5	Item 3 - Pin E

ITEM	QTY	PART NO	DESCRIPTION	
1	1	X3P5443	5 Circuit Housing	
2	5	X3P5138	Crimp Terminal	
3	1	X3P5580	5 Circuit Receptacle	
4	5		Cable Tie	
5	1'		22 AWG Red CSA Type TR-64 Coated Wire	
6	1'		22 AWG White CSA Type TR-64 Coated Wire	
7	1'		22 AWG Green CSA Type TR-64 Coated Wire	
8	1'		22 AWG Black CSA Type TR-64 Coated Wire	
9	1'		22 AWG Yellow CSA Type TR-64 Coated Wire	



# FIGURE B5: Current Cable Assembly P/N: E3W5040

DESCRIPTION	WIRE COLOR	FROM	ТО
VOL+	Red	Item 1 - Pin 1	ltem 3 - Pin A
VOL-	Black	ltem 1 - Pin 2	Item 3 - Pin B
Shield	White	ltem 1 - Pin 3	Item 3 - Pin C

ITEM	QTY	PART NO	DESCRIPTION	
1	1	X3P5174	3 Circuit Housing	
2	3	X3P5138	Crimp Terminal	
3	1	X3P5579	3 Circuit Receptacle	
4	5		Cable Tie	
5	0.9'		22 AWG Red CSA Type TR-64 Coated Wire	
6	0.9'		22 AWG Black CSA Type TR-64 Coated Wire	
7	0.9'		22 AWG White CSA Type TR-64 Coated Wire	



#### FIGURE B6: Voltage Cable Assembly P/N: E3W5041

DESCRIPTION	WIRE COLOR	FROM	ТО
DCD	Red	Item 2 - Pin 1	Item 1 - Pin 1
DSR	Gray	Item 2 - Pin 2	Item 1 - Pin 6
TD	Gray	Item 2 - Pin 3	Item 1 - Pin 2
CTS	Gray	Item 2 - Pin 4	Item 1 - Pin 7
RD	Gray	Item 2 - Pin 5	Item 1 - Pin 3
RTS	Gray	Item 2 - Pin 6	Item 1 - Pin 8
DTR	Gray	Item 2 - Pin 7	Item 1 - Pin 4
RI	Gray	Item 2 - Pin 8	Item 1 - Pin 9
COM	Gray	Item 2 - Pin 9	Item 1 - Pin 5
Not Used	Gray	Item 2 - Pin 10	Not Connected

ITEM	QTY	PART NO	DESCRIPTION
1	1	X3P5608	9 Circuit D-sub Connector
2	3	X3P5610	10 Circuit IDC Connector
3	1	X3W5073	10 Circuit Flat Cable



#### FIGURE B7: Term Cable Assembly P/N: E3W5042

DESCRIPTION	WIRE COLOR	FROM	ТО
Input 1	Red	Item 2 - Pin 1	Item 1 - Pin 1
CR1-A	Gray	ltem 2 - Pin 2	ltem 1 - Pin 6
Input 2	Gray	Item 2 - Pin 3	Item 1 - Pin 2
CR1-B	Gray	ltem 2 - Pin 4	Item 1 - Pin 7
Input Common	Gray	Item 2 - Pin 5	Item 1 - Pin 3
CR2-A	Gray	ltem 2 - Pin 6	Item 1 - Pin 8
Input 3	Gray	ltem 2 - Pin 7	Item 1 - Pin 4
CR2-B	Gray	Item 2 - Pin 8	Item 1 - Pin 9
Input 4	Gray	Item 2 - Pin 9	Item 1 - Pin 5
Not Used	Gray	Item 2 - Pin 10	Not Connected

ITEM	QTY	PART NO	DESCRIPTION
1	1	X3P5664	9 Circuit D-sub Connector
2	3	X3P5610	10 Circuit IDC Connector
3	1	X3W5073	10 Circuit Flat Cable



#### FIGURE B8: Remote Cable Assembly P/N: E3W5043

# APPENDIX C - OSCILLATOR MOTOR CABLE ASSEMBLY

DESCRIPTION	WIRE COLOR	FROM	ТО
Motor A+	White	Item 1 - Pin A	ltem 2 - Pin A
Motor A-	Red	ltem 1 - Pin B	Item 2 - Pin B
Motor B+	Black	Item 1 - Pin C	Item 2 - Pin C
Motor B-	Green	Item 1 - Pin D	Item 2 - Pin D



FIGURE C1: Oscillator Motor Cable - E3W5036

# APPENDIX D - REMOTE I/O INTERFACE



FIGURE D1: Lincoln Power Source Interface



FIGURE D2: Miller Power Source Interface:

FIGURE D3: Generic Welding Power Source Interface

Connect CR!-A and CR1-B to welding torch gun switch. This will allow the WOC-500 to remote control the welding power source. The arc active relay CR2 can be used to automatically start the travel speed controller. Connect CR2 to the travel forward or run input for the travel speed controller. CR1 and CR2 are N.O.dry relay contacts rated at 120 vac @ 1 amp non-inductive.

**Note**: if AC voltage is applied to the relays, install a 0.01 mfd 200 vdc ceramic capacitor across the relay contacts.